



SMARTPLANT 3D

(Diseño)



Contenido del Curso

1. SP3D Common Training

DURACIÓN

1 día

User Interface

- Overview
- Layout

Session Management

- Session template
- Session File
- Options

View Manipulations

- Common Views
- Zoom Tool
- Window Area
- Refresh View
- Active View Control
- Rotate View
- Looking at Surface

Formatting Active View

- View Format
- Surface Style Rules

Filters

- System
- Assembly
- Spatial (Volume or Planes)
- Logical Permission Group
- Object Types
- Properties

Insert Options

- Control Points / Notes / Hyperlink

Measure

- Distance
- Minimum Distance between Objects
- Angle

Tool Tips

Label Editor



Contenido del Curso (continuación)

2. SP3D Equipment Training

DURACIÓN

1 día

Overview

- Standard Parametric/Non-parametric Equipment Placement
- Modeling of equipments using primitive shape
- 3rd party software – SAT format (Solid Edge v-14)

Aspects

- Physical, Insulation, Maintenance, and so on ...

Ports

- Piping port
- Ducting port
- Cableway port
- Conduit port
- Cable port
- Foundation Port

Placing Design Equipment

- Equipment from Catalog (standard)
- By Shapes

Relationships / Constraints

- Mate
- Align
- Connect
- Minimum Distance (E-W, N-S, Vertical)
- Parallel
- Mate to Tangent Plane

SmartSketch Options

- Pinpoint
- Locate on Display List
- Locate on List Only

Manipulation Commands

- Select Command
- Delete Command
- Undo Command
- Move Command
- Rotate Equipment
- Rotate Command
- Open the properties page
- Copy/Paste Command

Place Imported Shape from File

- Equipment From SAT file

Place Equipment From PID

- Retrieving PID
- Placing Equipment from PID
- Comparing Data
- Updating Data

Nozzle Placement

- Placing Nozzles with Graphics
- Nozzles with no Graphics
- Nozzles from PID

Modification

Property Page



Contenido del Curso (continuación)

3. SP3D Structural Training

DURACIÓN

2,5 días

Overview

- Grids
- Coordinate Systems
- Smart Plant Structure

Grids & Coordinates

- Grid Wizard
- Placing Coordinate System
- Modifying Grids
- Adding Grid Planes
- Rotated Coordinate Systems
- Rotated Planes

Member Types

- Beams
- Columns
- Braces

Member Properties

- Name Rule - Naming rule
- Parent System
- Type Category
- Type
- Priority
- Continuity
- Cross section
- Section Standard
- Section Type
- Section Name
- Material
- Grade
- Angle
- Cardinal Point

Place Linear Member System

- Place Member Ribbon Bar

Frame Connections

- Flush
- Seated
- Centerline
- Axis
- Corner Brace
- Surface
- Unsupported
- Manual or Automatic rule-based selection

Vertical Brace Connections

- Rule-based Offset

Assembly Connections

- Assembly Connection Ribbon Bar
- Base Plate
- Splice
- Fitted Assembly Connection
- Corner Gusset Plates

Modifications

- Attributes
- Generic Move Command
- PinPoint
- Point Along Tool
- Frame connection

Slabs

- Coincident plane
- Offset from plane
- Angle from plane
- Point/Normal Vector
- 3 Point plane



Contenido del Curso (continuación)

Sketch 2D

- Basic Sketch 2D overview

Holes / Openings

- Sketch method
- Select an opening from Catalog

- Draw (Sketch 2D)

- Footings
- Footing Ribbon Bar
- Property Page
- Placement
- Modifications

Equipment Foundations

- Equipment Foundation Ribbon Bar
- Property Page
- Placement
- Modifications

Stairs/Ladders

- Settings
- Top Support
- Bottom Support
- Reference
- Position
- System
- Type
- Name
- Width
- Angle

Handrails

- Settings
- Properties
- Sketch Path
- Type
- Modifying Path

Reports

- Running Reports

4. SP3D Piping Training

DURACIÓN

3,5 días

Overview

- Pipeline
- Pipe Run
- Features
- Parts
- Port
- Path leg
- Connections

New Pipe Run

- Define the Pipe Run properties

Route Pipe Command

- Length Control Tool
- Route Pipe Run with PinPoint
- Angle Control Tool
- Pipe Run Smart Step Ribbon Bar

Working Plane Control Tool

- Plane Lock Options

Turn Type option

- Default Turn Options
- Selecting a Turn Type



Contenido del Curso (continuación)

Pipe Select Command

- Select Filter Options

Delete Command

- Delete Pipeline
- Delete Pipe Run
- Delete feature

Routing From End Features or Nozzle

- Connecting to End Feature
- Connecting to Nozzles

Routing To or From a Straight Feature

- Branch on Pipe Run
- Intersect to Branch

Insert Component command

- Selecting a Component
- Reference Position
- Point Along option
- Selecting Different Ports / Flip

Edit Commands

- Edit Straight Features
- Edit End Features
- Edit Run Change Features
- Editing features

Insert Split command

- Insert Split ribbon bar

Edit Properties Command

- Flow Direction
- Insulation
- Relation Tab

Route Pipe Run using the offset value

- Offset Control Tool

Insert Component – Piping Specialty / Instruments

- Component by Tag
- Piping Specialty
- Instruments

Routing Sloped Pipe

- Slope Format
- Route Sloped Run
- Turn Slope Lock On/Off

Route Flanged Pipe

- Flanged Spec
- Modifying Flanged Pipe

Route Using Spherical Coordinates

- Relative Tracking Mode

Routing Using PID (TEF)

- Retrieving PID
- Routing from PID
- Comparing Data
- Updating Data

TAPS

- Insert Tap Command

Reports

- Running Reports

Interactive Clash

- Setting Local IFC

Running Local IFC



Contenido del Curso (continuación)

5. SP3D Electrical Training

DURACIÓN

0,5 días

Overview

- Electrical System
- Cableways
- Cable tray / Conduit
- Cables

Route Cableway

- Define Properties
- Using Pinpoint
- Using SmartSketch
- From End Features
- To End Features
- To Straight Features
- Using Relative Tracking
- Using Spherical Coordinates
- Using Offset Option
- Routing From Ports
- Placing Transitions / Size Change

Branches

- Branch on a Run
- Intersect to Branch
- Branch using Pinpoint

Insert Component command

- Selecting a Component
- Reference Position
- Point Along option
- Selecting Different Ports / Flip

Routing Cableway – No Part Spec

- Routing Cableway

Insert Transition

- Without offset
- With Offset

Edit Commands

- Edit Straight Features
- Edit End Features
- Edit Cross Sections

Routing Conduits

- Conduit System
- Route Options

Conduit Fittings

- Insert Conduit Fittings

Place Electrical Equipment

- Placing Junction Box
- Placing Light Fixtures
- Creating MCC
- Placing Cable/Nozzle Ports

Placing Ducts

- Placing Ducts using Cableway

Insert Cables

- Selecting Equipment
- Selecting Cables
- Defining Properties

Define Cable Path

- Selecting Cableways
- Defining Exit/Entry points

Placing Cable Markers

Reports

Running Reports



Contenido del Curso (continuación)

6. SP3D HVAC Training

DURACIÓN

0,5 días

Route Duct Command

Start routing a Duct Run from:

- A point in space
- An existing Duct run
- An equipment HVAC port

Create Duct Run Dialog Box

Define the Duct Run properties

- System, Name, Spec, Required Flow rate, insulation, Max design velocity and Max. pressure loss.

Insert split Features

Insert Component Features

HVAC Division

Select the End Feature

Insert Transition Features

Insert surface mounted Features



Contenido del Curso (continuación)

7. SP3D Isometric Drawings Training

DURACIÓN

0,5 días

Extracting Pipeline Isometric Drawings

Creating Spools

Extracting Spool Drawings

Isometric Options Browser

Alias Options

Labels

- ComponentNote (Type 1 Labels)
- EndConnection (Connection note and nozzle note labels)
- Misc Spec labels (Pipeline header)
- Weld list labels
- DrawingFrame (title block labels)

Title block

- AttributeMAP
- Mapping attributes to the border

Material list

- Fixed - Style 1
- Variable - Style 2
- User-defined - Style 3
- Various material list options
- Material list labels

Weld list - wdf file

Definitions - ddf file

Creating new isometric style

- Using your own border template
- Modifying delivered style xml file to match
- Bulkloading the style

MTO neutral file



Contenido del Curso (continuación)

8. SP3D Drawing and Reports Training

DURACIÓN

0,5 días

Creating Drawings

- Volume Drawings
- Snapshot Drawings
- Manual Drafting
 - Graphic
 - Annotation
 - Labels
 - Dimensions
 - Title blocks

Running Reports



© 2009 Intergraph Corporation. Reservados todos los derechos.

El contenido de este documento es propiedad de Intergraph Corporation, o terceros relevantes, y está protegido según la ley de propiedad intelectual y el tratado internacional. Cualquier uso, duplicación y distribución no está autorizado y será considerado como una violación de la ley de propiedad intelectual aplicable y del tratado internacional.

Intergraph puede hacer mejoras y/o cambios de los productos y/o los programas descritos en esta publicación en cualquier momento sin previo aviso.

En ningún caso Intergraph será responsable de cualquier daño y/o perjuicio, por la descarga, la visualización, uso, duplicación, o distribución de cualquier contenido publicado por Intergraph, incluyendo, la posible pérdida o corrupción de datos.

www.intergraph.es

Departamento de Formación
Process, Power & Marine
Intergraph Corporation
Gobelas, 47-49
28023 - La Florida
Madrid (España)

P +34.91 708 88 00 **F** +34.91 372 80 21